

Underground Meter Base Installation

NOTE: IF EXTERIOR MOUNTED BREAKER AT METER BASE, USE 4 WIRE TYPE SE. CABLE FROM BREAKER(S) TO PANEL(S) IN BUILDING.

